

Produktblad Whirlwind MICMUTE PP

Whirlwind MICMUTE PP Microphone mutebox. Push on to talk, push off to mute.

The Micmute PP are configured as latching Push On; Push Off switch, meaning that the switch must be pushed and released to turn the signal on or off through the box. Each time the switch is pressed and released (PP), the signal is changed from one condition to the other. The PP have an indicator LED feature that is operational when the connected microphone preamp input is providing phantom power. The blue LED illuminates to indicate that the mic is live and signal is passing through the Micmute box. The LED is not functional when phantom power is not present.



XL1958908 Whirlwind MICMUTE PP 2470 kr inklusive moms

Lagerstatus: Ungefär 5 dagar